


# Rapture Async - Dual Channel Scalar Emitter



## How to start

**Step 1** - Download the Driver Software from the website : <http://girk-fit-niir.com/sfg/> or you can find the application in the **Google Play Store** and on **Apple App Store**. Just search for the name “**Scalar Field Generator**”. If you downloaded the application as first steps adjust the text size using the Text size adjustment buttons like on the picture bellow. Then select your connected emitter.



**Step 1.2**  
In the application select the connected emitter in this case the Rapture Async Emitter. This will unlock the Dual Mode. In this mode you can drive the emitter with 2 different vibration and make unique multi purpose fields. The app custom output frequency is precise between 2Hz-15Khz above this range your phone might give incorrect output frequency.


**Step 2** - Setup the proper mode on the emitter for Low or High level input using the small switch. As next step connect the emitter with the attached cable to your phone and set the maximum volume on your phone or connect it directly to an amplifier ( first recommended to use the emitter on Lowlevel ).



**Low level Mode** - The emitter is directly connected to your Phone / PC via the audio Cable - **Make sure the little switch is turned to the left side like on the picture above!**



**High level Mode** - The emitter is directly connected to a Stereo Amplifier ( Max 20Watt) - **Make sure the little switch is turned to the right side like on the picture above!**



The app screen while the emission is turned on.

**Step 3** - Start the application and choose any program then press the play button. **Important note:** Don't turn off your phone while the application is running. Your screen should be not turned off otherwise the emission will stop. *If you have an iPhone don't forget to unmute your phone with the switch on the side of your phone.*

**Step 4** - Place your crystal in the middle of the emitter and put your phone onto the charger and you can start enjoying any program you choose. Our suggestion is to start with the 512Hz or the 528Hz and try to connect to the field and to the crystal with your heart. You can connect this emitter to your brain with the 852 or 963 Hz. If your heart chakra is too much closed then you would probably not sense much but the device will still have an effect on you. Try to observe your mental state and try to dive into your imagination while you use the device. Your imagination and mental visualisation have a direct driving effect on the field characteristic this is how you can manipulate the energy field. We suggest to try in the application the solfeggio 12 sequence for sleeping. We realised on low power it can bring you a very deep and energising sleeping time. You can also place a bottle water on the emitter and subject to the scalar field for 1-2 hour on low power. Use for this procedure the 432Hz. This will make the water very energised and supporting any healing process if you drink it.

**What should I feel when my device is already running?** - Depending on the selected program you may feel different things. It is very common that you can hear a kind of high and soft ringing tone in your center of your brain as you look at the device and connect to the field mentally ( the quantum coils triggering your pineal gland ) , or you can feel a soft pressure at your heart chakra. After a while 30-50 min you can sense that you feel better more energetic or you are boosted. This is a low power system and meant for the continuous usage so you can sleep next to it or you can let it run any time you wish. You can expect more dream and astral remembrance if you sleep next to the emitter.

**IMPORTANT NOTE:** *The system works with your intention and boosting your energies and your mind. If you are in a sad ,angry or harsh mood then don't use the device and take the crystal away from the coil ( this stops the energy radiation because even if your coil doesn't running the system radiates the last programmed energies on a lower energy at least for 3-4 days long ) . Always put your intention into the crystal about what kind of energy do you want to create like healing, or boosting your brain, or you just want to have calming energies. Just choose a program and put the same intention into the crystal to ensure the best performance and effect.*

**Can I connect the emitter to a receiver?** - Yes we designed the coil to being able to driven with more power like with a hi-fi speaker or connect to a custom signal generator. On this way you can create a stronger field with bigger emission range. ( on 20 Watt approximately 15-20m radius which can cover your entire house ) . Your coil have 2 Input connector. 1, Is the low level 2.5mm Jack Audio input 2, The Dual channel / Stereo high power wire terminals. Using a small screwdriver you can connect and fix the cable end to the wire terminal.

**IMPORTANT NOTE:** *we are not recommending to use it on high power longer than 2 hour if you drive it with an amplifier. We would not suggest to use it over 15-20W music performance however the coil can be driven up to 40W . The coil is overheating over 45W sinus power. If you feel the coil is warmer than you could keep your finger on it then please lower the input power.*

I create this device with love and with helping intention. I wish you a wonderful time with your new energy source which can help you in your life in so many ways. In case you need any support or guidance feel free to connect with us via mail [support@girk-fit-niir.com](mailto:support@girk-fit-niir.com)

Namaste

Peter